

## Loudspeaker DSP settings for TH812

The settings provided in this document are the DSP settings that are used in the DNA series products available from Danley Sound Labs. These settings or more advanced proprietary settings are available by default with the purchase of those products. The DSP settings itemized below are being made available to provide a starting point for third party DSP processing. When using any third party DSP processing, some adjustment of the filters, particularly EQ bandwidth, may be necessary.

Please be certain to disconnect the loudspeaker before setting the limiters. Nobody wants to hear that racket and damage to the loudspeakers is practically guaranteed and unnecessary. If the amplifier used is unable to reach the output voltage listed for the loudspeaker before reaching amplifier output clip, set the limiter to engage before the amplifier output clips.

### Crossover:

Polarity: Normal

Relative Gain (assumes amplifiers with equal gain): 0dB

Relative Delay (in box crossover alignment only): 0mS

	Frequency (Hertz)	Slope (dB/Octave)	Type
High Pass Filter	25	24	Butterworth
Low Pass Filter	80	24	Butterworth

Equalization: None Required

### Limiters:

RMS Limiter: 140 Volts

Thermal Limiter: 80 Volts, 2.0 Seconds Attack, 1.0X Release (multiplier of Attack)

XMax Limiter: 130 Volts at 25 Hz